


**cs** Montážní list  
**da** Installationsvejledning  
**de** Installationsanleitung  
**el** Οδηγίες Εγκατάστασης  
**en** Installation Instructions  
**es** Instrucciones de montaje


**fi** Asennusohje  
**fr** Instructions d'installation  
**hu** Telepítési leírás  
**it** Istruzioni di montaggio  
**nl** Installatie-aanwijzing  
**pl** Instrukcja montażu



**pt** Instruções de montagem  
**sk** Návod na montáž  
**sv** Installationsanvisning  
**tr** Montaj talimatları  
**zh** 安装说明书

## RAB...




RAB11, RAB11.1, RAB21, RAB21.1, RAB31, RAB31.1







Dimensions in mm

**RAB11, RAB11.1**

- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y Control output "Valve actuator", AC 24...250 V
- D Zone valve or thermal valve


**RAB21, RAB21.1**  
Heating or Cooling

- D1 Zone valve or thermal valve for heating or cooling
- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat


**RAB21, RAB21.1**

Changeover for heating or cooling with external aquastat

- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y1 Control output "Valve actuator heating", AC 24...250 V
- Y2 Control output "Valve actuator cooling", AC 24...250 V
- S1 Aquastat e.g. Z182 / RYT182

**RAB31, RAB31.1**

- D1 Zone valve or thermal valve for heating
- D2 Zone valve or thermal valve for cooling
- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y1 Control output "Valve actuator heating", AC 24...250 V
- Y2 Control output "Valve actuator cooling", AC 24...250 V

**RAB91**

- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V